

PURO CLENZ

PuroClenz Standard (20 gram) Instructions:

***IMPORTANT:** to maximize the full effect of PuroClenz, do not treat vehicles in direct sunlight. It is recommended that the vehicle is clean before treatment, preferably detailed.*

1. Remove all personal belongings, floor mats, and any air fresheners from the vehicle
2. Make sure all doors and windows are closed during treatment. Open all air vents in the vehicle
3. Sun visors should be positioned half way down, in order to expose both sides of the visor. Any sunroof cover should be closed and all seat belts engaged for maximum exposure to the PuroClenz vapor
4. Place the PuroClenz “Warning Sticker” in a highly visible area of the vehicle to indicate that it is undergoing treatment.
5. Fill the designated PuroClenz cup to the fill line with room temperature water and place the cup in a center console, armrest, or cup holder
6. Tear open the foil pack, place the PuroClenz tablet into the cup of water, exit the vehicle, and close the door. Allow PuroClenz to generate vapor for 30 minutes (It is best to lock the doors and keep the keys so that nobody accidentally enters the vehicle during treatment)
7. After the initial 30 minutes, start the vehicle to run the AC on high for 10 minutes. (Note: quickly enter and exit the vehicle as you perform this step)
8. Next, turn the recirculation button (shown below) on high and allow to run for 10 minutes



9. Once 10 minutes have passed on recirculation mode, turn the vehicle off, exit, shut the door and allow PuroClenz to remain inside the vehicle for the required time (See “**Treatment Time**” on the back page)
10. Once this Treatment Time expires, remove the PuroClenz cup and dispose of the remaining liquid down the drain

11. Return to the vehicle and open all windows and doors. Start the vehicle for another 15 minutes in order to “air out” any remaining vapors
12. As in Steps 7 and 8, turn on the AC and then the recirculation for 10 minutes each, so that any fumes within the ventilation can also be removed
13. Please leave all the windows open for at least 30 minutes to properly allow the PuroClenz vapors to disperse outside the vehicle
14. **FINISHED!** The vehicle is now “PuroClenzed” and odor free. You will notice a slight odor that smells like Chlorine. This is normal and safe and will gradually dissipate. If the smell is bothersome, you may use a scented product to temporarily mask the PuroClenz smell as it dissipates. PuroClenz itself is not a masking agent and is meant to eliminate unpleasant odors entirely

Treatment Time (Included in Step 9)

Odors on 1-4 scale: **30 MINUTES**

Odors on 5 to 7 scale: **1.5-2 HOURS**

Odors on 8-10+ scale: **OVERNIGHT**