



Accelerator Instructions

Batteries not included

1. Insert 2 D batteries into the battery compartment on the back of accelerator box.
2. Attach one end of the clear tube onto the nozzle at the top of the accelerator.
3. Connect the open end of tube to the “ball” piece.
4. Use the clip on the back of the accelerator to connect it to either the handle or rim of bucket so that the “ball” can sit in the liquid (the box itself should never get wet, and should remain on the exterior of the bucket)
5. The power button is located on the top side of the box. Refer to the Application Instructions to see when you can turn on the PuroClenz Accelerator.

The PuroClenz Accelerator may be reused for future applications!

To Order More
Shop.puroclenz.com